TB 20 Terrace bracket 33080



Areas of application:

For the chased fixing of sheathed cables, flexible tubing and conduits, on and under plasterboard.

Installation Guide:

- Drill a 6mm Ø hole
- Insert the TA in the drill-hole
- · Click the TB onto the TA
- Put flexible pipes under the TB
- Push the TB tight with your thumb
- Cut the end points of the TB to the desired size

Product details:

Colour light grey
Content pack/box 25 / 600
Clamping range mm 200

Mounting and usage instructions:

The TB is fixed to the TA support anchor. Several TBs can be fixed to one TA. The fixing of the TBs can be done in several stages.

Product benefits/properties:

The TB provides a secure hold even with different conduits/cables dimensions. Fast cable placement with no plastering.

Technical data:

Material POM, UV stabilised

Temperature range: -20 $^{\circ}$ C up to +100 $^{\circ}$ C

silicon-free halogen-free

Weight per piece 13,30 g

GTIN (EAN)







With the TB in two sizes, Schnabl has in combination with the TA a system for all requirements - on or under plasterboard







