



■ Features :

- True sine wave output (THD<3%)
- High surge power up to 3000W
- U.P.S. mode and energy saving mode (selectable)
- High efficiency up to 91%
- Power ON-OFF switch
- Standby saving mode can be selectable
- Front panel indicator for operation status
- Thermostatically controlled cooling fan
- Protections: Bat. low alarm / Bat. low shutdown / Over voltage / Over temp. / Output short / Input polarity reverse / Overload / AC circuit breaker
- Application : Home appliance, power tools, office and portable equipment, vehicle and yacht ...etc.
- Built-in solar / AC charger
- Optional monitoring software
- 3 years warranty



SPECIFICATION

MODEL	TN-1500-112	TN-1500-124	TN-1500-148	TN-1500-212	TN-1500-224	TN-1500-248			
OUTPUT	RATED POWER (Typ.)	1500W							
	MAXIMUM OUTPUT POWER (Typ.)	1725W for 180 sec. / 2250W for 10 sec. / surge power 3000W for 30 cycles							
	AC VOLTAGE	Factory setting set at 110VAC		Factory setting set at 230VAC					
	AC VOLTAGE	100 / 110 / 115 / 120VAC selectable by setting button S.W		200 / 220 / 230 / 240VAC selectable by setting button S.W					
	FREQUENCY	60±0.1Hz 50/60Hz selectable by setting button S.W		50±0.1%Hz 50/60Hz selectable by setting button S.W					
	WAVEFORM	True sine wave (THD<3%) at rated input voltage							
	AC REGULATION (Typ.)	±3.0%							
	TRANSFER TIME (Typ.)	10ms inverter → by pass							
INPUT	SAVING MODE (Typ.)	Load ≤ 5W will be changed to standby mode							
	FRONT PANEL INDICATOR	Battery voltage level, output load level, saving mode, fault and operation status							
	BAT. VOLTAGE	12V	24V	48V	12V	24V			
	VOLTAGE RANGE (Typ.) Note.1	10.5 ~ 15VDC	21 ~ 30VDC	42 ~ 60VDC	10.5 ~ 15VDC	21 ~ 30VDC			
	DC CURRENT (Typ.) Note.5	150A	75A	37.5A	150A	75A			
	NO LOAD DISSIPATION	≤ 18W @ standby saving mode							
	OFF MODE CURRENT DRAW	≤ 1mA							
	EFFICIENCY (Typ.) Note.2	87%	89%	90%	88%	90%			
BATTERY INPUT PROTECTION	BATTERY TYPES	Open & sealed Lead Acid							
	FUSE	40A*5	30A*3	30A*2	40A*5	30A*3			
	BAT. LOW ALARM	11.3±4%	22.5±4%	45±4%	11.3±4%	22.5±4%			
	BAT. LOW SHUTDOWN	10.5±4%	21±4%	42±4%	10.5±4%	21±4%			
OUTPUT PROTECTION	REVERSE POLARITY	By internal fuse open							
	OVER TEMPERATURE	82°C ± 5°C	82°C ± 5°C	96°C ± 5°C	68°C ± 5°C	68°C ± 5°C			
		Protection type : Shut down o/p voltage, re-power on to recover ; by internal RTH3 detect on heatsink of power transistor							
	OUTPUT SHORT	Protection type : Shut down o/p voltage, re-power on to recover							
	OVER LOAD (Typ.)	105 ~ 115% load for 180 sec., 115% ~ 150% load for 10 sec.							
		Protection type : Shut down o/p voltage, re-power on to recover							
	CIRCUIT BREAKER	20A		10A					
ENVIRONMENT	GFCI PROTECTION	Optional (Only type F)							
	WORKING TEMP. Note.3	0 ~ +40°C @ 100% load ; 60°C @ 50% load							
	WORKING HUMIDITY	20% ~ 90% RH non-condensing							
	STORAGE TEMP., HUMIDITY	-30 ~ +70°C / -22 ~ +158°F, 10 ~ 95% RH							
SAFETY & EMC	VIBRATION	10 ~ 500Hz, 3G 10min./1cycle, 60min. each along X, Y, Z axes							
	SAFETY STANDARDS	UL458 (only for "GFCI" receptacle-Type F) None							
	LVD	None		EN60950-1					
	WITHSTAND VOLTAGE	Bat I/P - AC I/P:3.0KVAC Bat I/P - AC O/P:3.0KVAC AC O/P - FG:1.5KVAC							
	EMI CONDUCTION&RADIATION	Compliance to FCC class A		Compliance to EN55022 class B, 72/ 245/ CEE, 95/ 54/ CE, E-Mark					
AC CHARGER	EMS IMMUNITY	None							
	CHARGE CURRENT (Typ.)	5.5A	2.7A	1.35A	5.5A	2.7A			
	CHARGE VOLTAGE	14.3V±4%	28.5V±4%	57V±4%	14.3V±4%	28.5V±4%			
SOLAR CHARGER	MAX OPEN CIRCUIT VOLTAGE	25V	45V	75V	25V	45V			
	CHARGE CURRENT (max.)	30A							
OTHERS	CHARGE VOLTAGE	14.3V±4%	28.5V±4%	57V±4%	14.3V±4%	28.5V±4%			
	CONTROL WIRING	RJ11 -RS232 (Option)							
	DIMENSION	420*220*88mm (L*W*H)							
NOTE	PACKING	6.85Kg; 2pcs/14.7Kg/1.61CUFT							
		1. Output derating capacity referenced by curve 1. 2. Efficiency is tested by 1000W, linear load at 13V, 26V, 52V input voltage. 3. Output derating capacity referenced by curve 2. 4. All parameters not specified above are measured at rated load, 25°C of ambient temperature. 5. DC current is tested by 1500W, linear load at 13V, 26V, 52V input voltage.							

■ Instructions for TN-1500 monitoring software

1. Installation of TN-1500 unit and PC




Figure 1

2. Explanation of Monitoring Manu

2.1 Main Page




Figure 2

1. Setting: Adjustment for output voltage, charging related voltage, frequency, and operation mode. Please refer to Figure 3 for details.
2. Statistics: Calculate for the percentage of operating period for each operation mode. Please refer to Figure 4 for details.
3. R.C. Power off: Power can be turned ON or OFF at the remote location.
4. Pause: Stop refreshing the page of monitoring software.
5. Status of unit: Indicating current operating status of TN-1500.
6. Signals that display current condition of the unit.

2.2 Setting Page




Figure 3

1. User can adjust the settings based on the characteristics of batteries been used: Equalization Voltage, Floating Voltage, Alarm Voltage, and Shut-down Voltage. UPS Mode / Energy Saving Mode selection and AC output voltage and frequency can also be set in this page.
2. Read: Read current settings of the unit.
3. Write: Write the revised setting into the unit.
4. Load: Load in factory default settings.

2.3 Statistic Page





Figure 4

1. Start Date: Date that installing the monitoring software.
2. Reset Date: Date that resetting the statistics. The Start Date will not be influenced by resetting the statistics or turning off the unit.
3. Inverter time rate: Operating period of "Inverter Mode" represents how many percent of the whole operating period.
4. Bypass time rate: Operating period of "Bypass Mode" (energy provides directly by the utility) represents how many percent of the whole operating period.
5. Shut down rate: Percentage of time period that the unit is under the condition of shut down.
6. * Inverter time rate + Bypass time rate + Shut down rate = 100%
7. Solar time rate: Percentage of time period that the solar charger is functioning after turning on the TN-1500 unit.
8. Loading average: Average loading after turning on the TN-1500 unit.



■ AC Output Receptacles (optional)

Receptacle type	TYPE-A	TYPE-B	TYPE-C	TYPE-D	TYPE-E	TYPE-F
Country	USA	EUROPE	AUSTRALIA	U.K.	JAPAN	GFCI
Certificate						(Expect for 48V input)

