

PRODUCT-DETAILS

1722-184K

1722-184K Rámeček dvojnásobný, pro vodorovnou i svislou montáž 2 gang(s) IP20 Studio white Horizontal mounting - future linear



Obecné informace

Typ	1722-184K
Id výrobku	2CKA001754A4236
EAN	4011395050767
Katalogový popis	1722-184K Rámeček dvojnásobný, pro vodorovnou i svislou montáž 2 gang(s) IP20 Studio white Horizontal mounting - future linear
Detailní popis	With small corner radii for trunking systems.

Technické údaje

Number of Gangs	2
Design Range	future linear 63x63
Typ upevnění	Flush Mounted
Type of Fastening	Clamp
Mounting Orientation	Horizontal Vertical
Povrchová úprava	Untreated Glossy
Materiál	Thermoplastic
Label Space Provided	No
RAL Number	RAL 9016 - Traffic White
Barva	studio white

Údaje vnějšího prostředí

Krytí	IP20
Stav RoHS	Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019

Rozměry

Čistá šířka výrobku	151 mm
Čistá výška výrobku	12 mm
Čistá hloubka výrobku	80 mm
Čistá hmotnost výrobku	34 g

Balení

Úroveň balení 1, jednotky	carton 10 piece
Úroveň balení 1, šířka	141 mm
Úroveň balení 1, výška	96 mm
Úroveň balení 1, délka	175 mm
Úroveň balení 1, hrubá hmotnost	0.415 kg
Úroveň balení 1, EAN	4011395050767
Úroveň balení 2, jednotky	carton 100 piece
Úroveň balení 2, šířka	293 mm
Úroveň balení 2, výška	191 mm
Úroveň balení 2, délka	493 mm
Úroveň balení 2, hrubá hmotnost	4.558 kg
Úroveň balení 3, jednotky	3000 piece
Úroveň balení 3, šířka	0.8 m
Úroveň balení 3, výška	1.105 m
Úroveň balení 3, délka	1.2 m
Úroveň balení 3, hrubá hmotnost	156.74 kg

Objednací údaje

Minimální objednácní množství	1 piece
Číslo celního sazebníku	85389099
Země původu	Germany (DE)

Certifikáty a prohlášení (Číslo dokumentů)

Prohlášení o shodě - CE	2CKA200000E2639
Pokyny a příručky	No document needed
REACH Declaration	2CKA309999E9999
Informace RoHS	2CKA200000E2639

Dokumenty ke stažení

List s údaji, technické	No document needed
-------------------------	--------------------

informace

Pokyny a příručky

No document needed

Klasifikace

ETIM 7	EC000007 - Cover frame for domestic switching devices
ETIM 8	EC000007 - Cover frame for domestic switching devices
WEEE Category	Product Not in WEEE Scope
CN8	8538 90 99
Trída eClass	V11.0 : 27144001

Accessories

Identifier	Description	Type	Quantity	Unit Of Measure
2CKA001731A1916	1720-84 Rocker Switch Pull cord Without imprint studio white - 63x63	1720-84	1	piece
2CKA001710A3808	1740 DR/03-84 Cover Plate Volume controlLevel switch Turn button studio white 63x63	1740 DR/03-84	1	piece
2CKA001710A3512	1740 DRL-84-503 Cover Plates Level switch Turn button Symbol "3-level switch" studio white - 63x63	1740 DRL-84-503	1	piece
2CKA001710A3172	1740-84 Kryt spínače žaluziového, s otočným ovladačem Venetian blind Turn button Symbol "arrows" studio white - 63x63	1740-84	1	piece
2CKA001710A3161	1742-84 Kryt zaslepovací, s upevňovacími třmenem Blind cap 1 gang(s) 0 pole Flush Mounted studio white -63x63	1742-84	1	piece
2CKA001710A3991	1742-84-500 Cover Plates Blind cap 1 gang(s) 0 pole Flush Mounted studio white -63x63	1742-84-500	1	piece
2CKA001724A4368	1743/10-04-84 Cover Plate SAT 4 gang(s) studio white 63x63	1743/10-04-84	1	piece
2CKA001724A4377	1743-04-84 Cover Plate SAT 4 gang(s) studio white 63x63	1743-04-84	1	piece
2CKA001724A4332	1743-84-500 Cover Plates SAT 3 gang(s) studio white 63x63	1743-84-500	1	piece
2CKA001710A3173	1745-84 Cover Plate telephone connector boxes (VDo) studio white 63x63	1745-84	1	piece
2CKA001710A3993	1746/10-84-500 Cover Plates Telecommunication inserts 0 gang(s) studio white 63x63	1746/10-84-500	1	piece
2CKA001710A3167	1746-84 Intermediate Ring TAE; UAE / TAE; USB / VGA / HDMI / loudspeaker 1 gang(s) studio white 63x63	1746-84	1	piece
2CKA001710A4096	1747 BSI-84 Intermediate Ring Cover plate 1 gang(s) Flush Mounted studio white -63x63	1747 BSI-84	1	piece
2CKA001710A3863	1747 SI-84 Cover Plates Flush Mounted studio white -63x63	1747 SI-84	1	piece
2CKA001710A3861	1747-84 Intermediate Ring Cover plate Flush Mounted studio white -63x63	1747-84	1	piece
2CKA001710A3656	1748-84 Cover Plate Data connection 2 gang(s) studio white 63x63	1748-84	1	piece
2CKA001710A3163	1749-84 Vývodka kabelová, s odlehčovací sponou (bez svorkovnice) Cable outlet studio white 63x63	1749-84	1	piece
2CKA001710A3166	1750-84 Cover Plate BNC/TNC 2 gang(s) studio white 63x63	1750-84	1	piece
2CKA001723A0240	1751-84 Insert Loudspeaker 2 gang(s) studio white 63x63	1751-84	1	piece
2CKA001710A3175	1755 SL/PZ-84-101 Cover Plate Venetian blind Key Symbol "arrows" studio white - 63x63	1755 SL/PZ-84-101	1	piece
2CKA001753A0092	1756-84 Cover Plate Info light studio white - 63x63	1756-84	1	piece

2CKA001724A2761	1758-84 Kryt zásuvky komunikační, s popisovým polem (pro nosnou masku) For data connection housing 2 gang(s) studio white 63x63	1758-84	1	piece
2CKA001710A4106	1762-84-506 Cover Plates TDO 1 gang(s) studio white 63x63	1762-84-506	1	piece
2CKA001731A1877	1764 NLI-84 Rocker Switch/push button Single push button Without imprint studio white - 63x63	1764 NLI-84	1	piece
2CKA001710A3992	1766-84-500 Cover Plates TAE 0 gang(s) studio white 63x63	1766-84-500	1	piece
2CKA001753A0258	1770-84-103 Cover Plate Time switch Toggle Time indication studio white - 63x63	1770-84-103	1	piece
2CKA001753A0301	1771-84-103 Kryt ovládače časového mechanického Time switch Toggle Time indication studio white - 63x63	1771-84-103	1	piece
2CKA001751A3099	1785 JA/02-84 Rocker Venetian blind Single rocker Symbol "arrows" studio white	1785 JA/02-84	1	piece
2CKA001751A3088	1785 JA-84-500 Cover Plates Venetian blind Two-part rocker Symbol "arrows" studio white - 63x63	1785 JA-84-500	1	piece
2CKA001751A3128	1785 K-84-500 Cover Plates Switch/push button Two-part rocker None studio white - 63x63	1785 K-84-500	1	piece
2CKA001751A2992	1785/11-84 Rocker Switch/push button Hotel - room unit Two-part rocker studio white - 63x63	1785/11-84	1	piece
2CKA001751A3076	1785-84-500 Cover Plates Switch/push button Two-part rocker Without imprint studio white - 63x63	1785-84-500	1	piece
2CKA001751A3098	1786 JA/02-84 Rocker Venetian blind Single rocker Symbol "arrows" studio white	1786 JA/02-84	1	piece
2CKA001751A2998	1786/11-84 Rocker Switch/push button Hotel - room unit Single rocker studio white - 63x63	1786/11-84	1	piece
2CKA001751A3074	1786-84-500 Cover Plates Switch/push button Single rocker Without imprint studio white - 63x63	1786-84-500	1	piece
2CKA001751A2750	1788-84 Kryt spínače jednoduchý, s potiskem I/O, s červeným průzorem Switch/push button Single rocker Characters 0 and 1 studio white - 63x63	1788-84	1	piece
2CKA001751A2751	1789 H-84 Rocker Switch/push button Single rocker Heizung studio white - 63x63	1789 H-84	1	piece
2CKA001751A2754	1789 KI-84 Rocker Switch/push button Single rocker bell Symbol "bell" studio white - 63x63	1789 KI-84	1	piece
2CKA001751A3084	1789 LI-84-500 Cover Plates Switch/push button Single rocker Symbol "light" studio white - 63x63	1789 LI-84-500	1	piece
2CKA001751A3151	1789 N-84-500 Cover Plates Switch/push button Single rocker Without imprint studio white - 63x63	1789 N-84-500	1	piece
2CKA001751A3161	1789 ST-84-500 Cover Plates Switch/push button Single rocker Various symbols studio white - 63x63	1789 ST-84-500	1	piece
2CKA001751A2755	1789 TR-84 Rocker Switch/push button Single rocker Symbol "key/door" studio white - 63x63	1789 TR-84	1	piece
2CKA001751A3091	1789-84-500 Cover Plates Switch/push button Single rocker Without imprint studio white - 63x63	1789-84-500	1	piece
2CKA001710A4113	1790-592-84 Cover Plate Medical alarm studio white - 63x63	1790-592-84	1	piece
2CKA001710A3698	1794 TA-84 Cover Plate Thermostat Turn button studio white - 63x63	1794 TA-84	1	piece
2CKA001710A3544	1794-84 Cover Plate Thermostat studio white - 63x63	1794-84	1	piece
2CKA001710A4017	1795 HK-84 Kryt termostatu pro topení/ chlazení Thermostat Turn button studio white - 63x63	1795 HK-84	1	piece
2CKA001710A4049	1795 HKEA-84 Kryt termostatu pro topení/ chlazení, s posuvným přepínačem Thermostat Turn button 1 switchover studio white - 63x63	1795 HKEA-84	1	piece
2CKA001710A3725	1795 TA-84 Cover Plate Thermostat Turn button studio white - 63x63	1795 TA-84	1	piece
2CKA001710A3569	1795-84 Kryt termostatu prostorového, s otočným ovládním Thermostat Turn button studio white - 63x63	1795-84	1	piece

2CKA001753A0311	1796-84 Cover Plate Pull cord Without imprint studio white - 63x63	1796-84	1	piece
2CKA001710A3990	1800-84-500 Cover Plates Modular Jack 2 gang (s) studio white 63x63	1800-84-500	1	piece
2CKA001710A1551	1803-02-84-500 Cover Plates UAE/IAE (ISDN) 2 gang(s) studio white 63x63	1803-02-84-500	1	piece
2CKA001710A1550	1803-84-500 Cover Plates UAE/IAE (ISDN) 1 gang(s) studio white 63x63	1803-84-500	1	piece
2CKA002013A5407	20 EUAB-84 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) studio white - 63x63	20 EUAB-84	1	piece
2CKA002011A6207	20 EUC-84-500 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) studio white - 63x63	20 EUC-84-500	1	piece
2CKA002013A5418	20 EUCBDR-84 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) studio white - 63x63	20 EUCBDR-84	1	piece
2CKA002013A5286	20 EUCBL-84 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Green LED studio white - 63x63	20 EUCBL-84	1	piece
2CKA002013A5294	20 EUCBLI-84 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with White LED studio white - 63x63	20 EUCBLI-84	1	piece
2CKA002013A5268	20 EUCKS/DV-84 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) studio white - 63x63	20 EUCKS/DV-84	1	piece
2CKA002013A5372	20 EUCKS-84-500 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) studio white - 63x63	20 EUCKS-84-500	1	piece
2CKA002013A5441	20 EUCRB-84-500 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) studio white - 63x63	20 EUCRB-84-500	1	piece
2CKA002018A1509	20 EUK-84-500 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) studio white - 63x63	20 EUK-84-500	1	piece
2CKA002018A1520	20 EUKB-84 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid studio white - 63x63	20 EUKB-84	1	piece
2CKA002018A1529	20 EUKBR-84 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid studio white - 63x63	20 EUKBR-84	1	piece
2CKA002018A1540	20 EUKNB-84 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid studio white - 63x63	20 EUKNB-84	1	piece
2CKA002018A1551	20 EUKNBL-84 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid studio white - 63x63	20 EUKNBL-84	1	piece
2CKA002018A1563	20 EUKNBSL-84 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid studio white - 63x63	20 EUKNBSL-84	1	piece
2CKA002018A1564	20 EUKNBSL-84-101 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid studio white - 63x63	20 EUKNBSL-84-101	1	piece
2CKA002011A6209	20 EUN-84-500 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) studio white - 63x63	20 EUN-84-500	1	piece
2CKA002017A0786	20 MUC-84-500 Socket insert 1gang(s) studio white - 63x63	20 MUC-84-500	1	piece
2CKA002017A0807	20 MUCKS-84-500 Inserts with Cover Plate 1gang(s) studio white - 63x63	20 MUCKS-84-500	1	piece
2CKA001751A3170	2029 UC-84 Bell push-switch DND / MUR insert Bell Hotel - corridor unit Single push button studio white - 63x63	2029 UC-84	1	piece
2CKA002495A0086	2095 UC-84 Socket insert studio white - 63x63	2095 UC-84	1	piece
2CKA002190A0215	2190 EUC-84 Inserts with Cover Plate 1gang(s) studio white	2190 EUC-84	1	piece

2CKA002013A5477	23 EUCB-84 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) studio white - 63x63	23 EUCB-84	1	piece
2CKA002013A5451	2300 EUCB-84 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) studio white - 63x63	2300 EUCB-84	1	piece
2CKA002113A0511	2300 UCRKS-84-503 Inserts with Cover Plate 1gang(s) studio white - 63x63	2300 UCRKS-84-503	1	piece
2CKA002011A3833	2310 EUGL/VA-84-11 Socket insert Protective Contact (SCHUKO) 1gang(s) studio white - 63x63	2310 EUGL/VA-84-11	1	piece
2CKA002099A0214	2399 UCKS-84 Socket insert Safety Shutter 1gang(s) studio white - 63x63	2399 UCKS-84	1	piece
2CKA002099A0192	2399 UCKS-84-505 Inserts with Cover Plate 1gang(s) studio white - 63x63	2399 UCKS-84-505	1	piece
2CKA001719A0220	2518-WD-84 Cover Frame 1 gang(s) Flush Mounted studio white -63x63	2518-WD-84	1	piece
2CKA001751A3180	2520 KI-84-500 Cover Plates Switch/push button Single rocker studio white - 63x63	2520 KI-84-500	1	piece
2CKA001751A3199	2520 TR-84 Rocker Switch/push button Single rocker Symbol "key/door" studio white - 63x63	2520 TR-84	1	piece
2CKA001724A4256	2533-84 Cover Plate Bore hole 1 gang(s) studio white 63x63	2533-84	1	piece
2CKA001710A3646	2542 DR/01-84 Kryt spínače s otočným ovladačem, pro 3stup. spínač s nul. polohou Level switch Turn button Symbol "0-1-2-3" studio white - 63x63	2542 DR/01-84	1	piece
2CKA001710A3651	2542 DR/02-84 Cover Plate Level switch Turn button Symbol "1-2-3" studio white - 63x63	2542 DR/02-84	1	piece
2CKA001724A4388	2548-022 AR-84 Cover Plate Doctor 1 button(s) studio white - 63x63	2548-022 AR-84	1	piece
2CKA001724A4402	2553-84 Cover Plate XLR 1 gang(s) studio white 63x63	2553-84	1	piece
2CKA001753A0394	2561-02-84 Cover Plate Modular Jack 2 gang(s) studio white 63x63	2561-02-84	1	piece
2CKA001753A0403	2561-84 Cover Plate Modular Jack 2 gang(s) studio white 63x63	2561-84	1	piece
2CKA003116A0662	3120 EUCB-84 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) studio white - solo	3120 EUCB-84	1	piece
2CKA003117A0006	3151 UC-84 Cover Plate	3151 UC-84	1	piece
2CKA006115A0486	6108/61-84-500 Coverplate f. CE	6108/61-84-500	1	piece
2CKA006155A0063	6109/03-84-500 Coverplate f. RTC	6109/03-84-500	1	piece
2CKA006132A0379	6122/10-84-500 BW standard	6122/10-84-500	1	piece
2CKA006115A0183	6125/01-84-500 Control element 1g w. BAU	6125/01-84-500	1	piece
2CKA006115A0219	6125/02-84-500 Control element 1/2gang	6125/02-84-500	1	piece
2CKA006116A0174	6126/01-84-500 Control element 2g w. BAU	6126/01-84-500	1	piece
2CKA006116A0209	6126/02-84-500 Control element 2/4gang	6126/02-84-500	1	piece
2CKA006117A0200	6127/01-84-500 Control element 4g w. BAU	6127/01-84-500	1	piece
2CKA006117A0235	6127/02-84-500 Control element 4/8gang	6127/02-84-500	1	piece
2CKA006134A0334	6128/28-84-500 RTC Control element 2/4g	6128/28-84-500	1	piece
2CKA006135A0146	6129/01-84-500 Control element 3/6g w. IR	6129/01-84-500	1	piece

2CKA006430A0400	6430-84-102-500 Cover Plates Venetian blind Symbol "arrows" studio white - 63x63	6430-84-102-500	1	piece
2CKA006430A0306	6435-84 Kryt termostatu se spínacími hodinami, časovače nebo ovladače Busch-Timer, snímače kvality vzduchu Time switch studio white - 63x63	6435-84	1	piece
2CKA006470A0004	6476-84 Kryt spínače bezdotykového Proximity switch studio white - 63x63	6476-84	1	piece
2CKA006400A0059	6477-84 Cover Plate PowerDock 1 gang(s) studio white	6477-84	1	piece
2CKA006400A0047	6480/11-84-500 Complete Devices studio white	6480/11-84-500	1	piece
2CKA006400A0045	6480-84-500 Complete Devices studio white	6480-84-500	1	piece
2CKA006599A3009	6540-84-102-500 Cover Plates Dimmer studio white - 63x63	6540-84-102-500	1	piece
2CKA006599A2835	6541-84 Kryt modulu stmivacího výkonového nebo termostatu komerčního Cooling Central cover plate Without imprint studio white - 63x63	6541-84	1	piece
2CKA006599A3010	6543-84-101-500 Cover Plates Switch/dimmer Single push button Without imprint studio white - 63x63	6543-84-101-500	1	piece
2CKA006599A2908	6545-84 Control Element Dimmer Two-part button Without imprint with Neon lamp studio white - 63x63	6545-84	1	piece
2CKA006710A0011	6716 UJ-84-500 Sada Friends of Hue smart switch studio white - future linear	6716 UJ-84-500	1	piece
2CKA006730A0038	6731-84-500 Cover Plates studio white - 63x63	6731-84-500	1	piece
2CKA006730A0039	6732-84-500 Cover Plates studio white - 63x63	6732-84-500	1	piece
2CKA006730A0040	6733-84-500 Wall sensor studio white - 63x63	6733-84-500	1	piece
2CKA006730A0136	6736 FoH-84 Kryt pro Friends of Hue smart switch Switch/dimmer Two-part button studio white	6736 FoH-84	1	piece
2CKA006800A2834	6815-84-101-500 Cover Plates studio white	6815-84-101-500	1	piece
2CKA008200A0081	8253-84 Kryt pro reproduktor, s kulatou mřížkou (AudioWorld) Loudspeaker studio white 63x63	8253-84	1	piece
2CKA006220A0244	CP-FCC-84 C-plate Fan Coil	CP-FCC-84	1	piece
2CKA006220A0181	CP-RTC-84 C-plate RT sensor unit	CP-RTC-84	1	piece
2CKA006220A0214	MD-F-1.0.1-84 Movement detector	MD-F-1.0.1-84	1	piece
2CKA006220A0217	MSA-F-1.1.1-84 Mov. detector/actuator 1g	MSA-F-1.1.1-84	1	piece
2CKA006200A0086	MSA-F-1.1.1-84-WL WL-Mov. detector/act. 1g	MSA-F-1.1.1-84-WL	1	piece
2CKA006220A0139	SR-1-84 rocker 1gang	SR-1-84	1	piece
2CKA006220A0154	SR-2-84 rocker 2gang	SR-2-84	1	piece
2CKA006220A0145	SRB-1-84 rocker 1gang, blinds	SRB-1-84	1	piece
2CKA006220A0160	SRB-2-84 rocker 2g, blinds	SRB-2-84	1	piece
2CKA006220A0151	SRD-1-84 rocker 1gang, dimming	SRD-1-84	1	piece
2CKA006220A0166	SRD-2-L-84 rocker 2g, left, dimming	SRD-2-L-84	1	piece
2CKA006220A0260	SRD-2-R-84 rocker 2g, right, dimming	SRD-2-R-84	1	piece
2CKA006220A0142	SRL-1-84 rocker 1gang, lighting	SRL-1-84	1	piece
2CKA006220A0157	SRL-2-L-84 rocker 2g, left, lighting	SRL-2-L-84	1	piece
2CKA006220A0169	SRL-2-R-84 rocker 2g, right, lighting	SRL-2-R-84	1	piece
2CKA006220A0148	SRS-1-84 rocker 1gang, scene	SRS-1-84	1	piece
2CKA006220A0163	SRS-2-L-84 rocker 2gang, left, scene	SRS-2-L-84	1	piece
2CKA006220A0175	SRS-2-R-84 rocker 2g, right, scene	SRS-2-R-84	1	piece

Kategorie

Přístroje a rozváděče nízkého napětí → Switch Assortments → Frames

