



AC output side



DC input side



User's Manual



Video



IEC62368-1 BS EN/EN62368-1



UL62368-1



TPTC004



AS/NZS 62368.1



## Features

- Combining AC/DC charger, DC/AC Inverter, AC by-pass & support external MPPT solar charger
- AC utility charger up to 4520W
- UPS function (AC by-pass) without interruption, transfer time <10ms
- True sine wave output (THD<3%)
- High surge power up to 10KW
- Parallel synchroized operation up to 30KW (5+1 unit)
- Temperature controlled cooling fan
- AC output voltage and frequency selectable by DIP S.W
- Protections :  
Input : Reverse polarity / DC low alarm / DC low shutdown / Over voltage  
Output : Short circuit / Overload / Over temp.
- Battery over discharge protection (low voltage disconnect)
- 30°C ~+70°C wide operating temperature
- Suitable for lead-acid or li-ion batteries
- Support MODBus-RTU(RS-485) or CANBus protocol communication
- Graphical user interface controller CMU2E/CMU2E-R for status monitoring and control
- Conformal coating
- 5 years warranty

## Applications

- Home and office appliance
- Power tools
- Portable equipment
- Vehicle
- Yacht
- Off-grid solar power system
- Wireless network
- Telecom or datacom system

## Description

NTN-5K is a 5KW highly reliable off-grid true sine wave DC-AC power inverter with built-in AC charger and UPS function(AC by-pass). Its key features include: digital design with MCU control, streamlined control circuitry that quickly responds to environmental changes and improves reliability, high quality fan with low acoustic noise, 10KW peak power, adjustable AC output voltage and frequency, -30~+70°C wide. Operating temperature range, complete protection features, and etc. Combined with batteries, the NTN-5K is suitable for use in residential, commercial, marine, automobile, mine, construction site, and remote areas with no access to utility power, and the output can be used to power fans, TV, radio, phone charger, PC/laptop, lighting, induction stove, air conditioner, electromechanical tool, communication equipment, power distribution cabinet, outdoor camping equipment, marine AC power, factory equipment, and etc.

## Model Encoding

NTN - 5K - 2 24

Communication protocol option

DC input voltage (24: 24Vdc, 48: 48Vdc, 380: 380Vdc)

AC output voltage (1:100/110/115/120Vac, 2:200/220/230/240Vac)

Rated wattage

Series name

Type	Communication Protocol	Note
Blank	MODBus protocol	In Stock
CAN	CANBus protocol	In Stock

## GTIN CODE

MW Search: <https://www.meanwell.com/serviceGTIN.aspx>



## 5KW True Sine Wave Inverter with AC Charger / UPS

## NTN-5K series

## SPECIFICATION





MODEL NO.			NTN-5K-224 <input type="checkbox"/>		NTN-5K-248 <input type="checkbox"/>		NTN-5K-2380 <input type="checkbox"/>		
			<input type="checkbox"/> =Blank, CAN						
AC OUTPUT	RATED POWER(Continuous)		5000W						
	OVER RATED POWER(3 Min.)		5750W						
	PEAK POWER(10 Sec.)		7000W		7500W				
	SURGE POWER(30 Cycles)		8000W		10000W				
	AC VOLTAGE		Default setting set at 230VAC 200 / 220 / 230 / 240Vac selectable by DIP S.W						
	FREQUENCY		Default setting set at 50 ± 0.1Hz 50/60Hz selectable by DIP S.W						
WAVEFORM (Note. 1)		True sine wave (THD<3%)							
AC REGULATION		± 3.0% at rated input voltage							
DC INPUT	DC VOLTAGE		24Vdc		48Vdc		380Vdc		
	VOLTAGE RANGE (Typ.)		19 ~ 33Vdc		38 ~ 66Vdc		280 ~ 430Vdc		
	DC CURRENT (Typ.)		240A		120A		16A		
	NO LOAD DISSIPATION (Typ.)	NON-SAVING MODE	2.5A		1.4A		0.2A		
		SAVING MODE (Note. 5)	Default disable, auto detect AC output load ≤ 10W will be changed to saving mode <25W						
	POWER OFF CURRENT DRAW		≤ 2mA						
	EFFICIENCY (Typ.) (Note. 1)		91%		93%		94.5%		
	BATTERY TYPES		Lead Acid or li-ion						
PROTECTION	DC INPUT	ALARM	22 ± 0.5Vdc		44 ± 1Vdc		300 ± 5Vdc		
		SHUTDOWN	19 ± 0.5Vdc		38 ± 1Vdc		280 ± 5Vdc		
			25 ± 0.5Vdc		50 ± 1Vdc		335 ± 5Vdc		
			31 ± 0.5Vdc		62 ± 1Vdc		420 ± 5Vdc		
		SHUTDOWN	33 ± 0.5Vdc		66 ± 1Vdc		430 ± 5Vdc		
			30 ± 0.5Vdc		60 ± 1Vdc		400 ± 5Vdc		
	AC OUTPUT	REVERSE POLARITY	No damage, re-power on to recover after fault condition is removed					By internal fuse open	
		OVER TEMPERATURE	Shut down o/p voltage, recovers automatically after temperature goes down						
		OUTPUT SHORT	Shut down o/p voltage, re-power on to recover						
		OVER LOAD (Typ.)	105 ~ 115% load for 180 sec., 115% ~ 140% load for 10 sec.		105 ~ 115% load for 180 sec., 115% ~ 150% load for 10 sec.				
		CIRCUIT BREAKER	35A						
REMOTE CONTROL		Set remote ON/OFF control by front panel dry contact connector(by RELAY), Open : AC output OFF ; Short : AC output ON							
COMMUNICATION		MODBus-RTU (RS-485) / CANBus							
AC UPS MODE	AC INPUT RANGE		200/220/230/240Vac ± 16%, recover ± 13%						
	FREQUENCY RANGE		45 ~ 65Hz						
	TRASFER TIME(Typ.)		10ms inverter → AC by pass						
AC CHARGER	BOOST CHARGE VOLTAGE		Default 28.8Vdc		Default 57.6Vdc		Default 400Vdc		
	FLOAT CHARGE VOLTAGE		Default 27.6Vdc		Default 55.2Vdc		Default 385Vdc		
	CHARGE VOLTAGE RANGE		20 ~ 30Vdc		40 ~ 60Vdc		290 ~ 400Vdc		
	CONSTANT CURRENT		135A		70A		11.3A		
	MAX. CHARGE POWER		4050W		4200W		4520W		
	TEMPERATURE COMPENSATION		By external NTC						
	POWER FACTOR (Typ.)		PF>0.98/230VAC at full load						
	EFFICIENCY (Typ.)		91%		93%		94%		
	AC CURRENT (Typ.)		25A/230VAC						
	INRUSH CURRENT (Typ.)		50A/230VAC						
ENVIRONMENT	LEAKAGE CURRENT(Peak)		4.7mA/264VAC						
	WORKING TEMP.		-30 ~ +70℃ (Refer to "Derating curve")						
	WORKING HUMIDITY		20% ~ 90% RH non-condensing						
	STORAGE TEMP., HUMIDITY		-30 ~ +70℃ / -22 ~ +158°F, 10 ~ 95% RH non-condensing						
	VIBRATION		10 ~ 500Hz, 3G 10min./1cycle, 60min. each along X, Y, Z axes						
SAFETY & EMC (Note.4)	SAFETY STANDARDS		CB IEC62368-1, UL62368-1, CSA C22.2 No. 62368-1, TUV BS EN/EN62368-1, AS/NZS 62368.1, EAC TP TC 004 approved						
	WITHSTAND VOLTAGE (Note. 6)		DC I/P - AC: 3.0KVAC AC - FG: 1.5KVAC						
	ISOLATION RESISTANCE (Note. 6)		DC I/P - AC O/P, DC I/P - FG, AC O/P - FG: 100M ohms / 500VDC / 25℃ / 70% RH						
	EMC EMISSION	Parameter	Standard		Test Level / Note				
		Radiated	BS EN/EN55032(CISPR32), FCC		Class A				
		Conducted	BS EN/EN55032(CISPR32), FCC		Class A				
		Harmonic Current	BS EN/EN61000-3-2		Class A				
		Voltage Flicker	BS EN/EN61000-3-3		-----				
	EMC IMMUNITY	BS EN/EN55035, EN61000-6-2							
		Parameter	Standard		Test Level / Note				
ESD		BS EN/EN61000-4-2		Level 3, 8KV air ; Level 2, 4KV contact					
Radiated		BS EN/EN61000-4-3		Level 3					
EFT / Burst		BS EN/EN61000-4-4		Level 3					
Surge		BS EN/EN61000-4-5		Level 4, 2KV/Line-Line 4KV/Line-Earth					
Conducted		BS EN/EN61000-4-6		Level 3					
Magnetic Field		BS EN/EN61000-4-8		Level 4					
Voltage Dips and Interruptions		BS EN/EN61000-4-11		>95% dip 0.5 periods, 30% dip 25 periods, >95% interruptions 250 periods					
OTHERS	MTBF		200.9K hrs min. Telcordia TR/SR-332 (Bellcore) ; 17.8K hrs min. MIL-HDBK-217F (25℃)						
	DIMENSION		460*211*83.5mm (L*W*H)						
	PACKING		10.5Kg; 1pcs/ 10.5Kg/ 1.25CUFT						
NOTE		1.Efficiency, AC regulation and THD are tested by 75% load, linear load at 25Vdc/50Vdc/400Vdc input voltage. 2.All parameters not specified above are measured at 25Vdc/50Vdc/400Vdc input and 25℃ of ambient temperature and set to factory setting. 3.The tolerance of each voltage value by models is: 224 → ± 0.5V; 248 → ± 1V; 2380 → ± 5V. 4.The power supply is considered as an independent unit, but the final equipment still need to re-confirm that the whole system complies with the EMC directives. For guidance on how to perform these EMC tests, please refer to "EMI testing of component power supplies." (as available on <a href="https://www.meanwell.com/Upload/PDF/EMI_statement_en.pdf">https://www.meanwell.com/Upload/PDF/EMI_statement_en.pdf</a> ) 5.Saving mode only activates when the unit is used independently and the RPL switch is in the ON position. 6.During withstand voltage and isolation resistance testing, the screw "A" shall be temporarily removed, and shall be installed back after the testing. ※ Product Liability Disclaimer : For detailed information, please refer to <a href="https://www.meanwell.com/serviceDisclaimer.aspx">https://www.meanwell.com/serviceDisclaimer.aspx</a>							



## SPECIFICATION

MODEL NO.			NTN-5K-124 <input type="checkbox"/>		NTN-5K-148 <input type="checkbox"/>		
			<input type="checkbox"/> =Blank, CAN				
AC OUTPUT	RATED POWER(Continuous)		4000W				
	OVER RATED POWER(3 Min.)		4600W				
	PEAK POWER(10 Sec.)		5600W		6000W		
	SURGE POWER(30 Cycles)		7000W		8000W		
	AC VOLTAGE		Default setting set at 110VAC 100 / 110 / 115 / 120Vac selectable by DIP S.W				
	FREQUENCY		Default setting set at 60±0.1Hz 50/60Hz selectable by DIP S.W				
	WAVEFORM (Note. 1)		True sine wave (THD<3%)				
	AC REGULATION		±3.0% at rated input voltage				
DC INPUT	DC VOLTAGE		24Vdc		48Vdc		
	VOLTAGE RANGE (Typ.)		19 ~ 33Vdc		38 ~ 66Vdc		
	DC CURRENT (Typ.)		200A		100A		
	NO LOAD DISSIPATION (Typ.)	NON-SAVING MODE	2.5A		1.4A		
		SAVING MODE (Note. 5)	Default disable, auto detect AC output load≤10W will be changed to saving mode <25W				
	POWER OFF CURRENT DRAW		≤2mA				
	EFFICIENCY (Typ.) (Note. 1)		89%		91%		
BATTERY TYPES		Lead Acid or li-ion					
PROTECTION	DC INPUT	LOW	ALARM	22±0.5Vdc		44±1Vdc	
			SHUTDOWN	19±0.5Vdc		38±1Vdc	
			RESTART	25±0.5Vdc		50±1Vdc	
		HIGH	ALARM	31±0.5Vdc		62±1Vdc	
			SHUTDOWN	33±0.5Vdc		66±1Vdc	
			RESTART	30±0.5Vdc		60±1Vdc	
	REVERSE POLARITY		No damage, re-power on to recover after fault condition is removed				
	AC OUTPUT	OVER TEMPERATURE		Shut down o/p voltage, recovers automatically after temperature goes down			
		OUTPUT SHORT		Shut down o/p voltage, re-power on to recover			
		OVER LOAD (Typ.)		105 ~ 115% load for 180 sec., 115% ~ 150% load for 10 sec. Protection type : Shut down o/p voltage, re-power on to recover			
		CIRCUIT BREAKER		50A			
	FUNCTION	REMOTE CONTROL		Set remote ON/OFF control by front panel dry contact connector(by RELAY), Open : AC output OFF ; Short : AC output ON			
COMMUNICATION		MODBus-RTU (RS-485) / CANBus					
AC UPS MODE	AC INPUT RANGE		100/110/115/120Vac±16%, recover±13%				
	FREQUENCY RANGE		45 ~ 65Hz				
	TRASFER TIME(Typ.)		10ms inverter → AC by pass				
AC CHARGER	BOOST CHARGE VOLTAGE		Default 28.8Vdc		Default 57.6Vdc		
	FLOAT CHARGE VOLTAGE		Default 27.6Vdc		Default 55.2Vdc		
	CHARGE VOLTAGE RANGE		20 ~ 30Vdc		40 ~ 60Vdc		
	CONSTANT CURRENT		120A		60A		
	MAX. CHARGE POWER		3600W		3600W		
	TEMPERATURE COMPENSATION		By external NTC				
	POWER FACTOR (Typ.)		PF>0.98/115VAC at full load				
	EFFICIENCY (Typ.)		89%		91%		
	AC CURRENT (Typ.)		20A/110VAC				
	INRUSH CURRENT (Typ.)		25A/110VAC				
LEAKAGE CURRENT(Peak)		4.7mA/264VAC					
ENVIRONMENT	WORKING TEMP.		-30 ~ +70℃(Refer to "Derating curve")				
	WORKING HUMIDITY		20% ~ 90% RH non-condensing				
	STORAGE TEMP., HUMIDITY		-30 ~ +70℃ / -22 ~ +158°F, 10 ~ 95% RH non-condensing				
	VIBRATION		10 ~ 500Hz, 3G 10min./1cycle, 60min. each along X, Y, Z axes				
SAFETY & EMC (Note.4)	SAFETY STANDARDS		CB IEC62368-1, UL62368-1, CSA C22.2 No. 62368-1, TUV BS EN/EN62368-1, EAC TP TC 004 approved				
	WITHSTAND VOLTAGE		DC I/P - AC:3.0KVAC AC - FG:1.5KVAC				
	ISOLATION RESISTANCE		DC I/P - AC O/P, DC I/P - FG, AC O/P - FG: 100M ohms / 500VDC / 25℃ / 70% RH				
	EMC EMISSION	Parameter	Standard		Test Level / Note		
		Radiated	FCC		Class A		
OTHERS	MTBF	200.9K hrs min. Telcordia TR/SR-332 (Bellcore) ; 17.8K hrs min.		MIL-HDBK-217F (25℃)			
		DIMENSION		460*211*83.5mm (L*W*H)			
	PACKING		10.5Kg; 1pcs/ 10.5Kg/ 1.25CUFT				
NOTE		1.Efficiency, AC regulation and THD are tested by 75% load, linear load at 25Vdc/50Vdc input voltage. 2.All parameters not specified above are measured at 25Vdc/50Vdc input and 25℃ of ambient temperature and set to factory setting. 3.The tolerance of each voltage value by models is: 124→±0.5V; 148→±1V. 4.The power supply is considered as an independent unit, but the final equipment still need to re-confirm that the whole system complies with the EMC directives. For guidance on how to perform these EMC tests, please refer to "EMI testing of component power supplies." (as available on <a href="https://www.meanwell.com/Upload/PDF/EMI_statement_en.pdf">https://www.meanwell.com/Upload/PDF/EMI_statement_en.pdf</a> ) 5.Saving mode only activates when the unit is used independently and the RPL switch is in the ON position. ※ Product Liability Disclaimer : For detailed information, please refer to <a href="https://www.meanwell.com/serviceDisclaimer.aspx">https://www.meanwell.com/serviceDisclaimer.aspx</a>					


## DERATING CURVE



## CHARGING CURVE

☉ Default 3 stage charging curve

3 Stage




☉ Embedded 3 stage charging curves

MODEL	Vboost	Vfloat	C.C	Adjustable by MODBus / CANBus
124	Default 28.8Vdc	27.6Vdc	120A max.	20~30Vdc
224			135A max.	
148	Default 57.6Vdc	55.2Vdc	60A max.	40~60Vdc
248			70A max.	
380Vdc	Default 400Vdc	385Vdc	11.3A max.	290~400Vdc


☉ Suitable for lead-acid batteries (flooded, Gel and AGM) or li-ion

## BLOCK DIAGRAM



## Function Manual

### 1.Support MODBus / CANBus Communication



※ Please refer to the user manual for detailed instructions.

### 2.Remote ON/OFF Control

PAR1/PAR2	Remote ON/OFF	AC Output Status
Pin1:3	Short	AC output ON
Pin1:3	Open	AC output OFF

### 3.AC Output Voltage、Frequency、Power saving mode selectable by DIP SW



AC Output Voltage、Frequency、Power saving mode selectable by DIP SW

S1	S2	S3	S4
OFF	OFF : 100Vac or 200Vac	ON : 50Hz	ON : Saving mode
OFF	ON : 110Vac or 220Vac		
ON	OFF : 115Vac or 230Vac	OFF: 60Hz	OFF: Non-Saving mode
ON	ON : 120Vac or 240Vac		



#### 4.3Ø 4W and 1Ø 3W AC output Voltage connection selectable by DIP SW



◎3Ø 4-wire / Y




Fig 4.1

S1	S2	AC output phase
OFF	OFF	L1, 0°
OFF	ON	L2, -120°
ON	OFF	L3, +120°

Note: Please refer to 5.3 Three-phase 4-wire output on page 23 of the user manual for detailed instructions.

◎1Ø 3-wire(Split phase system only supports 124 and 148)




Fig 4.2

S1	S2	AC output phase
OFF	OFF	L1, 0°
ON	ON	L2, +180°

Note: Please refer to 5.4 Single-phase 3-wire Output on page 27 of the user manual for detailed instructions.

#### 5.Temperature compensation(3 stage only)

Temperature compensation function to prolong battery life for lead-acid batteries. Temperature compensation range is 0 ~ 40°C.

The battery temperature sensor comes along with the charger can be connected to the unit to allow temperature compensation of the charging voltage.

If the sensor is not used, the charger works normally.



## 6.AC Output Parallel Function

NTN-5K has the built-in active current sharing function and can be connected in parallel, up to 6 units, to provide higher AC output power as exhibited below :

※ The inverter should be paralleled using short and large diameter wiring and then connected to the load.

※ The total output current must not exceed the value determined by the following equation:

Maximum output current at parallel operation = (Rated current per unit) x (Number of unit) x 95% ; when parallel unit less than 6.

※ PAR1/PAR2, PRL Function pin connection

Parallel	PSU1		PSU2		PSU3		PSU4		PSU5		PSU6	
	PAR1	PRL	PAR1	PRL	PAR1	PRL	PAR1	PRL	PAR1	PRL	PAR1	PRL
1 unit	X	ON	—	—	—	—	—	—	—	—	—	—
2 unit	V	ON	V	ON	—	—	—	—	—	—	—	—
3 unit	V	ON	V	OFF	V	ON	—	—	—	—	—	—
4 unit	V	ON	V	OFF	V	OFF	V	ON	—	—	—	—
5 unit	V	ON	V	OFF	V	OFF	V	OFF	V	ON	—	—
6 unit	V	ON	V	OFF	V	OFF	V	OFF	V	OFF	V	ON










Fig 6.1




















If the lines of PAR1 / PAR2 are too long, they should be twisted in pairs to avoid the noise.




**LED STATUS**

Normal work:













	Green	Orange	Red
<b>Status</b>	 Inverter OK  System check	 Remote off  Saving mode	 Abnormal Status (See below table)

	Green	Orange	Red
<b>DC Input</b>	 25~31Vdc  50~62Vdc  335~420Vdc  Maintain	 22~25Vdc  44~50Vdc  300~335Vdc  Charging	 <22Vdc or >31Vdc  <44Vdc or >62Vdc  <300Vdc or >420Vdc

Load	Green	Orange	Red
<b>Inverter Mode</b>	 <40% load	 40~80% load	 >80% load
<b>Bypass Mode</b>	 <40% load	 40~80% load	 >80% load

	Green	Orange	Red
<b>AC Input</b>	 Utility OK  Utility error  Utility disconnected	-----	-----

Abnormal status :

LED Indicator	Abnormal Indication
<b>Status</b>  <b>DC Input</b>  <b>Load</b> 	Output overload or AC output short circuit
<b>Status</b>  <b>DC Input</b>  <b>Load</b> 	Abnormal DC voltage
<b>Status</b>  <b>DC Input</b>  <b>Load</b> 	Over temperature or Fan lock
<b>Status</b>  <b>DC Input</b>  <b>Load</b> 	Inverter fail



Light



Light off




Flash



## MECHANICAL SPECIFICATION

(Unit: mm , tolerance  $\pm 0.5\text{mm}$ )

Case No.223




### ※ Mounting Instruction

Hole No.	Recommended Screw Size	MAX. Penetration Depth L	Recommended mounting torque
①	M4	5mm	7~10Kgf-cm

### ※ Terminal Pin No. Assignment

Pin No.	Assignment	AC input	AC output	Maximum mounting torque
1	FG	1 2 3	1 2 3	18Kgf-cm
2	AC/N			
3	AC/L			



### ※ AC IN Connector Pin No. Assignment (COMM):

Pin No.	Function	Description
1	GND-AUX	Auxiliary voltage output GND.
2	D+/CANH	For MODBus model: Data line used in MODBus interface.(Note) For CANBus model: Data line used in CANBus interface.(Note)
3	D-/CANL	For MODBus model: Data line used in MODBus interface.(Note) For CANBus model: Data line used in CANBus interface.(Note)
4	+5V_AUX	Auxiliary voltage output, 4.5~5.5V, referenced to GND_AUX2 (pin1)

Note: Isolated signal, referenced to GND\_AUX2

### ※ Control Pin No. Assignment (CRL):

Pin No.	Function	Description
1,3	RL	Short: Termination resistors(120Ω) For MODBus/CANBus communication, please use Jumper (pin1,3)
2,4	NC	No need to communicate, please use Jumper (pin2,4)

※ AD1,AD2 switch for MODBus/CANBus interface address setting, please refer to the user manual for more details

### ※ Control Pin No. Assignment (Power ON/OFF) : HRS DF11-04DP-2DS or equivalent

Pin No.	Function	Description
1,2,3,4	Power ON/OFF	The unit can be completely turned ON/OFF by dry contact between Pin 1,2 & 3,4 Power ON : Short Pin1 to 2 and Pin3 to 4 ; Power OFF : Pin1 ~ Pin4 open.






### ※ Control Pin No. Assignment (PAR1,PAR2) : HRS DF11-08DP-2DS or equivalent

Pin No.	Function	Description
1	+5V_AUX2	Auxiliary voltage output, 4.5~5.5V, referenced to GND_AUX2 (pin2). (Only for REMOTE ON-OFF)
2	GND_AUX2	Auxiliary voltage output GND_AUX2 (pin2).
3	REMOTE ON/OFF	The AC output of the unit can be turned ON/OFF by dry contact between Remote ON/OFF and +5V_AUX2. (Note) Short : AC output ON ; Open : AC output OFF
4	SOLAR_ON_OFF	External MPPT charger control, referenced to GND_AUX2 (pin2).
5	DA	Data line used for parallel control.
6	SYNC_BUS	Signal for parallel operation.
7	DB	Data line used for parallel control.
8	SYNC_BUS2	Signal for parallel operation.







Note: Isolated signal, referenced to GND\_AUX2

### ■ Accessory List






※ NTC Sensor mating along with NTN-5K (Standard accessory)



Item		Quantity
①	<p>NTC sensor wire</p>  	1
②	<p>NTC mating wire</p>  	1
<p>Connection Diagram</p> 		

※ Power ON/OFF mating along with NTN-5K (Standard accessory)

Item		Quantity								
①	<p>Power ON/OFF mating wire</p>  <table border="1" data-bbox="670 1321 767 1411"><tr><td>1</td><td>Red</td></tr><tr><td>2</td><td>Red</td></tr><tr><td>3</td><td>Black</td></tr><tr><td>4</td><td>Black</td></tr></table>  <p>HRS DF11-4DP-2DS or equivalent</p>	1	Red	2	Red	3	Black	4	Black	1
1	Red									
2	Red									
3	Black									
4	Black									
②	<p>Power ON/OFF mating wire</p>   <table border="1" data-bbox="681 1722 778 1816"><tr><td>1</td><td>Red</td></tr><tr><td>1a</td><td>Red</td></tr><tr><td>2</td><td>Black</td></tr><tr><td>2a</td><td>Black</td></tr></table> 	1	Red	1a	Red	2	Black	2a	Black	1
1	Red									
1a	Red									
2	Black									
2a	Black									
Connection Diagram										
 <p>Connect to Power ON/OFF</p> <p>Extend cable by customer</p> <p>Connected</p> <p>Connect to NTN-5K</p> <table border="1" data-bbox="1254 1986 1351 2038"><tr><td>Red</td><td>Red</td></tr><tr><td>Black</td><td>Black</td></tr></table>			Red	Red	Black	Black				
Red	Red									
Black	Black									

※ Terminal protector mating along with NTN-5K (Standard accessory)

Item		Quantity
①	  	1
②		1
③		4




## ■ TYPICAL APPLICATION



- ① Battery Bank
- ② Off-Grid DC/AC Inverter (NTN series)
- ③ AC Outlet




- ① Utility Input (Shore)
- ② Battery Bank
- ③ Off-Grid DC/AC Inverter (NTN series)
- ④ AC Outlet



- ① Utility Inlet
- ② Battery Bank
- ③ Off-Grid DC/AC Inverter (NTN series)
- ④ AC Outlet
- ⑤ MPPT Charger (External)
- ⑥ Solar Panel (External)

## SYSTEM CONFIGURATION



- ① Battery Bank
- ② Off-Grid DC/AC Solar Inverter (NTN series)
- ③ AC Outlet